

CertiQ on Boomer E2 C Battery

All available information for the specified machine types



Operation

Drilling
Total drill meters
Drill meters per motor hour
Drill hours per motor hours, %
Drill meters per drill hour
Utilization
Available time
Motor hours
Drill hours
Hydraulic pump hours
Idle hours
Average drill hours
Average hydraulic pump hours
Average idle hours
Utilization %
Location
Site position

Reports

Excel reports
Report subscription
Notification
Mail notification
SMS notification

Administration (admins only)

User settings
Machine settings
Infrastructure
Organization settings
Machine communication

Maintenance

Diagnostic
Active alarms
No. of alarms
Alarm type trending (motor/hydraulics/others)
Alarm frequency (Count and time for each type)
Acknowledge alarm
Connectivity
Last communication
Service
No. of machines in overdue status
No. of reported services
Predicted date for next service
Hours to next service

Available alarms

Auto drill stop override warning
Boom in ambiguous position warning
Boom sensor in emergency mode critical
Compressor air pressure low warning
Cradle sensor in emergency mode critical
Electrical pump motor stopped critical
Emergency stop activated critical
Hydraulic oil level low critical
Hydraulic oil temp high warning
Hydraulic positioning pressure low warning
Invalid parallel reference for feeder direction warning
Lever not ok warning
Limp home mode warning
Lubrication oil pressure low critical
Module status bad warning
Navigation invalid warning
No contact with module critical
Power supply failure warning
SOC shutdown override warning
Total station navigation unreliable warning

(Some variations of supported alarms may exist due to model year and motor alternative)